# Transmission Power Monitoring System Test Plan

| Test 1: Secure access to Raspberry Pi dashboard                | 5  |
|--|----|
| Preconditions:   | 5  |
| Test Actions:  | 5  |
| Expected Outcomes:   | 5  |
| Results and Comments:  | 5  |
| Test 2: Are all sensors providing readings to the Raspberry Pi | 6  |
| Preconditions:   | 6  |
| Test Actions:  | 6  |
| Expected Outcomes:   | 6  |
| Results and Comments:  | 6  |
| Test 3: Set the site name                                      | 7  |
| Preconditions:   | 7  |
| Test Actions:  | 7  |
| Expected Outcomes:   | 7  |
| Results and Comments:  | 7  |
| Test 4: Set the transmitter name                               | 8  |
| Preconditions:   | 8  |
| Test Actions:  | 8  |
| Expected Outcomes:   | 8  |
| Results and Comments:  | 8  |
| Test 5: Set the site code                                      | 9  |
| Preconditions:   | 9  |
| Test Actions:  | 9  |
| Expected Outcomes:   | 9  |
| Results and Comments:  | 9  |
| Test 6: Set site longitude                                     | 10 |
| Preconditions:   | 10 |
| Test Actions:  | 10 |
| Expected Outcomes:   | 10 |
| Results and Comments:  | 10 |
| Test 7: Set site latitude                                      | 11 |
| Preconditions:   | 11 |
| Test Actions:  | 11 |
| Expected Outcomes:   | 11 |
| Results and Comments:  | 11 |
| Test 8: Set the coefficients                                   | 12 |

| <b>5</b>  | 40 |
|---|----|
| Preconditions:                                      | 12 |
| Test Actions:                                       | 12 |
| Expected Outcomes:                                  | 12 |
| Results and Comments:                               | 12 |
| Test 9: Set the Resistances                         | 13 |
| Preconditions:                                      | 13 |
| Test Actions:                                       | 13 |
| Expected Outcomes:                                  | 13 |
| Results and Comments:                               | 13 |
| Test 10: Set the flow rate                          | 14 |
| Preconditions:                                      | 14 |
| Test Actions:                                       | 14 |
| Expected Outcomes:                                  | 14 |
| Results and Comments:                               | 14 |
| Test 11: View the calculated power                  | 15 |
| Preconditions:                                      | 15 |
| Test Actions:                                       | 15 |
| Expected Outcomes:                                  | 15 |
| Results and Comments:                               | 15 |
| Test 12: Secure access to Grafana dashboard         | 16 |
| Preconditions:                                      | 16 |
| Test Actions:                                       | 16 |
| Expected Outcomes:                                  | 16 |
| Results and Comments:                               | 16 |
| Test 13: View data for Rowridge site, transmitter 3 | 17 |
| Preconditions:                                      | 17 |
| Test Actions:                                       | 17 |
| Expected Outcomes:                                  | 17 |
| Results and Comments:                               | 17 |
| Test 14: End to end change of input temperature     | 18 |
| Preconditions:                                      | 18 |
| Test Actions:                                       | 18 |
| Expected Outcomes:                                  | 18 |
| Results and Comments:                               | 18 |
| Test 15: View Data in Influx DB                     | 19 |
| Preconditions:                                      | 19 |
|   |    |

| Test Actions:         | 19 |
|-----------------------|----|
| Expected Outcomes:    | 19 |
| Results and Comments: | 19 |

# Test 1: Secure access to Raspberry Pi dashboard

#### Preconditions:

• Make sure all parts of the system are online.

#### **Test Actions:**

- 1. Visit the Raspberry Pi dashboard in the browser. (http://hostname:4000/ui).
- 2. Enter the username.
- 3. Enter the password.
- 4. Then click sign in.

### **Expected Outcomes:**

• You should be asked to sign in and then once signed in you should be able to see the Raspberry Pi dashboard.

# Test 2: Are all sensors providing readings to the Raspberry Pi

#### Preconditions:

• Test 1 has been completed.

#### **Test Actions:**

1. Navigate to the 'Thermistor In' and 'Thermistor Out' sections of the dashboard.

### **Expected Outcomes:**

• You should be able to see a reading for resistance in ohms, a coefficient value, and a reading for the temperature in degrees Celsius.

### Test 3: Set the site name

### Preconditions:

• Test 2 has been completed.

### **Test Actions:**

1. Enter the name 'Rowridge' into the site name input in the 'site configuration' section.

### **Expected Outcomes:**

• You should see the site name update in the site values section of the dashboard.

### Test 4: Set the transmitter name

### Preconditions:

• Test 3 has been completed.

#### **Test Actions:**

1. Enter the name 'Transmitter3' into the 'Transmitter Name' input in the 'site configuration' section.

### **Expected Outcomes:**

• You should see the transmitter name update in the 'Site Values section of the dashboard.

### Test 5: Set the site code

### Preconditions:

• Test 4 has been completed.

### **Test Actions:**

2. Enter the site code 'ROW' into the 'Site Code' input in the 'site configuration' section.

### **Expected Outcomes:**

• You should see the site code update in the 'Site Values section of the dashboard.

# Test 6: Set site longitude

### Preconditions:

• Test 5 has been completed.

#### **Test Actions:**

1. Enter the '-1.365939941365424' into the 'Site Longitude' input in the 'Site Configuration' section.

### **Expected Outcomes:**

• You should see the sites longitude update in the site configuration section of the dashboard.

### Test 7: Set site latitude

### Preconditions:

• Test 6 has been completed.

#### **Test Actions:**

1. Enter the '50.67010550875724' into the 'Site Latitude' input in the 'Site Configuration' section.

### **Expected Outcomes:**

• You should see the sites latitude update in the site configuration section of the dashboard.

### Test 8: Set the coefficients

### Preconditions:

• Test 7 has been completed.

#### **Test Actions:**

1. Enter '0.0035' into the 'Coefficient In' and 'Coefficient Out' inputs in the 'Testing Sensor Configuration' section.

### **Expected Outcomes:**

• You should see the coefficients in the 'Sensor Values' section of the dashboard update to the coefficients entered.

### Test 9: Set the Resistances

#### Preconditions:

• Test 8 has been completed.

#### **Test Actions:**

2. Enter '114' into the 'Resistance In' input, then enter '128' into the 'Resistance Out' input in the 'Testing Sensor Configuration' section.

### **Expected Outcomes:**

• You should see the resistance in and out change in the 'Sensor Values' section of the dashboard update to the resistances entered.

### Test 10: Set the flow rate

### Preconditions:

• Test 9 has been completed.

### Test Actions:

3. Enter '40' into the 'Flow Rate' input in the 'Testing Sensor Configuration' section.

### **Expected Outcomes:**

• You should see the flow rate change in the 'Sensor Values' section of the dashboard update to the resistances entered.

# Test 11: View the calculated power

### Preconditions:

• Tests 8, 9, and 10 have been completed.

### **Test Actions:**

1. Navigate to the 'Power Calculation' section of the dashboard.

### **Expected Outcomes:**

• The 'Power' dial should read as 112 KW.

### Test 12: Secure access to Grafana dashboard

#### Preconditions:

- Tests 8, 9, and 10 has been completed.
- Open a new browser tab.

#### **Test Actions:**

- 1. Visit the Grafana dashboard in the browser. (http://hostname:3000)
- 2. You will then be prompted for a username and password.
- 3. Enter the username.
- 4. Enter the password.
- 5. Click sign in.
- 6. Then click on the ArqivaTempTransmitter dashboard.

### **Expected Outcomes:**

• You should see a dashboard with a list of sites and a map displaying site locations.

# Test 13: View data for Rowridge site, transmitter 3

#### Preconditions:

• Test 12 has been completed.

#### **Test Actions:**

- 1. Click on Rowridge in the list of sites to the left of the map.
- 2. Scroll down to 'Transmitter 3'.
- 3. Expand 'Transmitter 3'.

### **Expected Outcomes:**

• You should be able to see the transmitter 3 section expanded displaying the power level (112), temperature out (80), and a temperature history.

### Test 14: End to end change of input temperature

#### Preconditions:

• Test 13 has been completed.

#### **Test Actions:**

- 1. Navigate to the Raspberry Pi Dashboard (http://hostname:4000/ui).
- 2. Scroll down to the 'Testing Sensor Configuration' section.
- 3. Ensure 'Resistance In' is set to 114, otherwise change it to 114.
- 4. Ensure 'Coefficient In' is set to 0.0035, otherwise change it to 0.0035.
- 5. Ensure 'Resistance Out' is set to 128, otherwise change it to 128.
- 6. Ensure 'Coefficient Out' is set to 0.0035, otherwise change it to 0.0035.
- 7. Ensure 'Flow Rate' is set to 40, otherwise change it to 40.
- 8. Scroll up to the 'Power Calculation' section.
- 9. Press the 'Send Immediate Reading' button.
- 10. Navigate back to 'Rowridge transmitter 3' on the Grafana page(http://hostname:3000)

#### **Expected Outcomes:**

• The 'Power Level' should display 112 and the 'Temperature Out' should display 80.

#### Test 15: View Data in Influx DB

#### Preconditions:

• Test 14 has been completed.

#### **Test Actions:**

- 1. Visit the Influx DB dashboard in the browser. (http://localhost:5000/).
- 2. Enter the username.
- 3. Enter the password.
- 4. Click sign in.
- 5. Click 'Data' from the menu on the left of the screen.
- 6. Select 'Buckets'.
- 7. Click 'TransmitterPower'.
- 8. In the 'From' box select 'TransmitterPower', then select 'TransmitterReadings' from the filter box that appears next to the 'From' box.
- 9. Tick the filter boxes 'coefficientln', 'powerLevel', 'resistanceln', and 'templn' and then press submit.

### **Expected Outcomes:**

• The graph should display 4 values, coefficientIn (3,5), powerLevel (112), resistanceIn (114) and tempIn (40).